







INSTALLATION MANUAL
Sectional Industrial Door
Low installation


English












5







5.1








6a












6b





9



10

10.1–10.3








10.4–10.5

10.4–10.5


L

R


10.1–10.3




10.1




10.2




10.3




10.4a





10.5a




10.4b




10.5b




11




11.1













11.2




11.3




12a ProPlus




12b ProTrend




12b.1




12b.2




12b.3




12b.4




12b.5




12b.6




12b.7



12b.8




12b.9




12c

ProTrend ProPlus


12c.1



12c.2




12c.3




12c.1-12c.8

12c.1 - 12c.8


12c.4




12c.5





12c.6











12c.7









12c.8









13a ProPlus



13b ProTrend





14




15




[Ru] Число оборотов пружин
[En] No. of spring turns
[De] Federspannung
[Fr] Nombres de tours des ressorts
[Cz] Počet otáček pružin
[Pl] Liczba obrotów napięcia sprężyny
[NI] Een aantal slagen van de veer
[Fi] Jousien kierrosten lukumäärä
[Da] Antal omgange fjederen drejes
[No] Antall tørn på fjær
[Se] Antal spända fjädervarv
[Ua] Число оборотів пружин




15.1




15.2




15.3




15.4




15.5




16






16.1






16.2




16.3a



16.3b



17




17.1-17.2


17.3

17.4-17.5


17.1




17.2




17.3




17.4



17.5



18



max 7x24h

19

